

Technical Newsletter nº 6/2014 2014-08-04

ADJUSTMENT OF THE THERMOSTAT TEMPERATURE COMPENSATION

Procedure

Press the **PROG** key for **2 seconds** and release.

keys STBY, VENT, UP and DOWN light up.

Press the **UP** key for **5 seconds**.

Just the UP key remains light up.

With **short presses** on the **PROG** key select the compensation value according to the following table:

0º	1 bip
-1º	2 bips
-2º	3 bips
-3º	4 bips
+1º	5 bips
+2º	6 bips
+3º	7 bips

Confirm the selection with a **short press** on the **UP** key.

Applies to:

C-CLIMA	>=V2.6
C-CLIMA4	>=V2.6
C-TERMO	>=V2.6
C-TERMO4	>=V2.6
D-TERMO4	>=V2.6
D-TERMO5	>=V2.6